



## How to format an SDHC card too work with 4341 Lab 2

NOTE: This tutorial is for windows 10. However, other versions of windows will be more or less identical.

**Step 1:** Type “disk management” into the search bar at the bottom left of the desktop and press enter. This should bring up the disk management window




**Step 2:** Scroll to the SD card on the list in the bottom half. Right click on the partition and select “delete volume”



**Step 3:** After this is complete, right click again and select “create new simple volume”. NOTE: You MUST create a volume smaller than 2GB to format with the filesystem that works for this lab.

**Step 4:** Right click the new volume and select “format”. You must format using the “FAT” option.



An SD card formatted this way, with the hints provided on the canvas should work, even if it is a newer SDHC card!